









COMPONENTS




HARDWARE

A	B	C	D
 M6 x 45 mm 2 pcs.	 50 mm 2 pcs.	 2 pcs.	 1 pc.
E	F		
 8 x 28 mm 12 pcs.	 1 pc.		


TOOLS REQUIRED




STEP 1



STEP 2



STEP 3



RUBY ROCKER(#6502)

62450

Assembly Instructions

