








ITEM NAME/NOM D'ITEM: FREYCINET DINING CHAIR
 ITEM #/NO. ITEM: 703987/703988

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)	(4)
			A  X3 (M6x35mm) B  X3 (M6x18mm) C  X1 (M4)

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE


I



II



III



For missing parts or damaged parts, please call /
 Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico: (866)-798-6663