



## Care & Cleaning

Our fabrics are designed for outdoor use. To keep your fabric looking its best, we recommend cleaning the fabric at the first signs of dirt or stains.

For routine maintenance of your fabrics, we recommend cleaning each spring season.

### Normal Stains/Dirt

1. Remove loose dirt with soft bristle brush or hose down with cold water.
2. Clean with mixture of water and mild soap. Rub in mixture with soft brush and allow to thoroughly soak into the fabric.
3. Rinse thoroughly with cold water and air-dry.
4. Never use water over 100 degrees Fahrenheit. Do not machine-dry. For light cleaning, avoid the use of detergents.

### Stubborn Stains/Dirt

1. Before bleach cleaning, make sure fabric is dry and has been vacuumed, and that space is ventilated.
2. Prepare a 10% bleach solution in water.
3. Test the solution in an inconspicuous location first before applying over the rest of the fabric.
4. Apply the cleaning solution using a misting spray bottle.
5. Work the solution into the affected area by lightly scrubbing the area with a sponge or soft bristle brush. Make sure to work from the outside of the stain inward so as not to spread the stain and rinse your sponge or brush frequently.
6. Allow cleaning solution to linger on the stain no more than 1 hour.
7. Rinse thoroughly to remove all residual bleach from the fabric.
8. Allow fabric to air dry.
9. Repeat process if necessary.

