All Weather Furnishings

Step 1 Attach leg assemblies to table top using (8) 2-1/2" chair bolts.

Model:

RT448


- (1) Table top
- (2) Leg Assemblies (2) Brace
- (1) Hardware pack

TOOLS NEEDED



Step 2 Attach braces to leg assemblies using (4) 2-1/2" screws.

Description Qty. A - 14 X 2.50 HEX WASHER T-A ALCHM 8 B - .273 X 2.50 SOCKET WAFER A 4



Leg Assembly

Table top



Join the POLYWOOD® Community

Share in the love of outdoor living, recycling, and more...







@POLYWOODINC



youtube.com/polywood



POLY-WORLD



POLYWOOD




To view our full warranty, please visit the warranty page on our website at polywoodinc.com/resources.

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 457-3284 or email support@polywoodinc.com

POLYWOOD

Assembly Instructions



- 1. Unfold chair
- 2. Remove shipping caps from rear brackets

VND38
Vineyard Folding Chair



20-Year Warranty

To view our full warranty, please visit polywoodoutdoor.com/warranty

Easily register your product using one of the methods below:

Text POLYWOOD to 71403

Receive a link to register online

- or -


Register on our website

register.polywoodoutdoor.com

— or —

Send a Picture

Take a photo of the icon below and text it to 71403 (US only)





Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (877) 457-3284 or email support@polywoodoutdoor.com





Share your space

We love to see where our furniture ends up — snap a pic and share it on Instagram or Facebook!

#polywood



Watch & Learn

For assembly videos and more, visit youtube.com/polywood



Cleaning Tips

Even POLYWOOD gets dirty — here are some ways to help keep it clean:

For a quick clean:

Simply wipe down with soap and water.

For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.