
Product Images





Short Description

Emma Natural Dining Arm Chair KIT-9197U by Sika Design

Description

The Emma Natural Dining Arm Chair (KIT-9197U) by Sika Design is an all-weather piece created to be both elegant and durable. With its eye-pleasing open-weave design and easy barrel silhouette, it makes a comfortable choice for dining alfresco on a patio or terrace. Crafted with ultra-durable polyethylene

ArtFibre™ wicker wrapped around a weatherproof AluRattan™ frame, this outdoor dining chair stands up to regular outdoor use. With its stack ability, maintenance-free design, and enduring style, the Emma Dining Chair is a practical choice for home, commercial, and hospitality settings.

Includes

- One (1) Emma Natural Dining Arm Chair KIT-9197U

Dimensions

- 24.8" W x 24.8" D x 31.5" H (17 lbs.)
- Seat Height: 19.72"
- Arm Height: 25.2"

Features

- Weatherproof AluRattan™ frames are sleek, durable
- Ultra-durable polyethylene ArtFibre™ wicker is all-weather, recyclable, and resistant to fading or cracking
- Cushions are resilient and provide maximum support and comfort
- Quick drying foam ensures moisture doesn't stay trapped in the cushion
- Available in Sunbrella fabric, which is distinctive, fade resistant and easy to clean
- Premium commercial-grade materials ensure durability and longevity for both commercial and residential spaces
- Stackable design makes storage and transportation easy
- No Assembly Required

Warranty

Sika Design's warranty covers manufacturing defects; normal wear and tear is not included. With a little bit of care, your furniture will outlive the warranty for many years.

- Sika Design offers a limited 2-year warranty. If a Sika Design product is found to be defective in that time period and reported with supporting photos, Designerie will, at its sole discretion instruct repairs, refund or replace the product.

Care and Maintenance

HDPE Wicker: To clean HDPE wicker, rinse with cool water, and use a cloth with mild dish soap to wipe down and remove dust and residue. Use cool water to wipe away any soapy residue. Dry with a soft cloth.

Cushions & Outdoor Fabric: Regular cleaning with mild soap and water will help prevent the build-up of dirt, which can generate mildew. Simply spot-treat stains with mild soap and water, rinse, and allow the fabric to air dry. Cushions will dry much faster when removed from the frames and placed on their sides or edges. For more information, please visit the fabric manufacturer's website.

Covers & Storage: When not in use, we recommend using a protective cover with your furniture. During harsh weather and extreme temperatures, we recommend storing the cushions in a shed or garage and covering the frames with protective covers. If you store the frames indoors during the winter, avoid storing them upside down, which can trap moisture.

About the Manufacturer

Sika Design, founded in 1942 by Ankjær Andreasen, is a leading Danish furniture manufacturer renowned for its timeless designs and exceptional craftsmanship. From humble beginnings crafting wicker products during World War II to becoming a global force in furniture design, Sika Design has remained true to its Scandinavian roots while embracing innovation. With a diverse range of furniture and decor, including iconic rattan pieces

and modern outdoor collections, each item reflects a blend of traditional craftsmanship and contemporary design. Committed to sustainability and social responsibility, Sika Design's global presence reflects its dedication to bringing Scandinavian excellence to homes and businesses worldwide.

Additional Information

SKU	KIT-9197U
Brand	Sika Design
Ships Out Estimate	3 - 5 Business Days
Residential Warranty	2 Years

Emma Natural Dining Arm Chair KIT-9197U by Sika Design

\$737.00

